


Safety is the first sign of respect for staff and their work environment, preventing any potential risks that could affect people. Personal protective equipment is equipment designed to protect against occupational hazards and should be used when risks cannot be sufficiently controlled by technical means of collective protection or by work organization procedures.

Therefore, the NAVACEL management, leads the deployment of this policy, at all levels of the organization and determines the mandatory individual protection equipment to use:.


- Indirect Personnel:   

- Direct Personnel:    

Works in height: harness always and anchored to a fixed point  , consult procedure of work in height.








Work in confined spaces: with autonomous mask  , consult work procedure in confined spaces.

**** Exceptions **** → Whenever you are in a narrow and confined space it is understood that the helmet will not be indispensable, as well as in the cabin of shot and paint.

When welding with the semiautonomous welding screen, we will not use the helmet. 

This Policy will be reviewed annually

Erando, May 2018
Emilio Celorio Torre – General Manager

HELMET	JOB	Específic ppe	Sing	
YELLOW	Shot	Scuba		
	Painting	Mask with filter		
	Ajusters			
GREEN	Machining			
BLUE	Pawn			
	Cylinder	Dark glasses to protect the view of the torch		
	Oxicutting			
	Boilemakers	Blowtorch	Dark glasses, sleeves, gaiters	
		Dot	Welding Screen	
Grind		Grinding Screen		
ORANGE	Welders	Semiautomátic	Welding shield, apron	
		Submerged arc	Apron	

La Seguridad constituye el primer signo de respeto hacia el personal y su entorno de trabajo, previniendo cualquier riesgo potencial que pudiera afectar a las personas. Un equipo de protección individual es un equipo destinado a proteger de los riesgos en el trabajo, deberán utilizarse cuando los riesgos no puedan ser suficientemente controlados por medios técnicos de protección colectiva o por procedimientos de organización del trabajo.

Por ello, la dirección de NAVACEL, lidera el despliegue de esta política, a todos los niveles de la organización y determina los equipos de protección individual obligatorios a utilizar:



Personal indirecto



Personal directo



Trabajos en altura: arnés siempre y anclado a un punto fijo , consultar procedimiento de trabajos en altura.



Trabajos en espacios confinados: con máscara autónoma , consultar procedimiento de trabajos en espacios confinados.

****Excepciones**** → Siempre que se esté en un espacio angosto y confinado se entiende que no será indispensable el casco, así como en la cabina de granalla y de pintura.







Cuando se esté soldando con la pantalla semiautónoma de soldar tampoco utilizaremos el casco.



La revisión de ésta Política se llevará a cabo anualmente

En Erandio, Mayo 2018
Emilio Celorio Torre – Director General



CASCO	PUESTO		EPI específico	Señalética
AMARILLO	Granalla		Escafandra	
	Pintura		Máscara con filtro	
	Ajustadores			
VERDE	Mecanizado			
AZUL	Peón			
	Cilindro		Gafas oscuras para proteger la vista del soplete	
	Oxicorte			
	Caldereros	Soplete	Gafas oscuras, manguitos, polainas	
		Puntear	Pantalla soldar	
		Esmerilar	Pantalla esmerilar	
NARANJA	Soldadores	Semiautomática	Pantalla soldar, mandil	
		Arco Sumergido	Mandil	